(G2 PRO)   HOW TO OPERATE OR SET THE DISPLAY

1. Data
· Press "M" enter the settings parameter，then press "M" button will show
· P1（10C）、P2（km/h）、P3（00）、P4（48V）、P5（00）、P6（00/99）。

P01, enter the wheel diameter setting, press the up key or press down button to adjust the setting (in inches) (don't change)

P02, means km/h or MPH, press the up key or press down button to adjust.

P03, set the max speed。00means max speed, 01mean min speed.

P04, means battery voltage, 48V. (don't change)

P05，00 means zero speed starting, 01 means non-zero speed starting.

P06，you can not change it, two versions, 00 or 99, if you changed it, pls try which one is right.